



WGA600N Game Adapter Settings

Wireless	Network N		
WPA in use?	Yes / No	WPA Key:	

- 1. Connect your laptop to the Game Adapter Ethernet port.
- 2. Set your laptop network settings (if necessary):

IP address: 10.xx.yy.6 (xx.yy = team number)

Subnet mask: 255.0.0.0 Default gateway: 10.xx.yy.2

- 3. Turn on power to the Game Adapter
- Open a web browser on your laptop and go to the Game Adapter url: http://10.xx.yy.1
- 5. Enter User Name and Password (default is "admin" for both).
- 6. Select "Basic" at top of page.
- 7. Verify correct Game Adapter network settings:

IP Address: 10.xx.yy.1 Subnet Mask: 255.0.0.0 Default Gateway: 10.xx.yy.4

If no changes are needed go to step 8. If you made changes, select "Save Settings", "Reboot Now" and go to step 5.

- 8. Select "Wireless" on Network Setting menu at top of page.
- 9. Enter the Wireless Network Name for the event (see top of this page).
- 10. Verify correct wireless settings:

802.11 Band: 5GHz 802.11 Mode: 802.11n only Transmission Rate: Best (automatic)

Channel Width: 20MHz

11. If WPA is not being used, select:
Wireless Security Mode: None

12. If WPA is being used, select:

Wireless Security Mode: WPA Personal WPA Mode: Auto (WPA or WPA2)

Cipher Type: TKIP or AES

Pre-Shared Key: enter the event WPA Key (see top of this page)

- 13. Select "Save Settings" and "Reboot Now".
- 14. Disconnect laptop and re-connect the Ethernet cable from the cRIO to the Game Adapter.

WGA600N Game Adapter Settings

Wireless Network Name (SSID):					
WPA n use?	Yes / No	WPA Key: (if used)			

- 1. Connect your laptop to the Game Adapter Ethernet port.
- 2. Set your laptop network settings (if necessary):

IP address: 10.xx.yy.6 (xx.yy = team number)

Subnet mask: 255.0.0.0
Default gateway: 10.xxx.yy.2

- 3. Turn on power to the Game Adapter
- 4. Open a web browser on your laptop and go to the Game Adapter url: http://10.xx.yy.1
- 5. Enter User Name and Password (default is "admin" for both).
- 6. Select "Basic" at top of page.
- 7. Verify correct Game Adapter network settings:

IP Address: 10.xx.yy.1 Subnet Mask: 255.0.0.0 Default Gateway: 10.xx.yy.4

If no changes are needed go to step 8. If you made changes, select "Save Settings", "Reboot Now" and go to step 5.

- 8. Select "Wireless" on Network Setting menu at top of page.
- 9. Enter the Wireless Network Name for the event (see top of this page).
- 10. Verify correct wireless settings:

802.11 Band: 5GHz 802.11 Mode: 802.11n only Transmission Rate: Best (automatic)

Channel Width: 20MHz

11. If WPA is <u>not</u> being used, select:
Wireless Security Mode: None

12. If WPA is being used, select:

Wireless Security Mode: WPA Personal WPA Mode: Auto (WPA or WPA2)

Cipher Type: TKIP or AES

Pre-Shared Key: enter the event WPA Key (see top of this page)

- 13. Select "Save Settings" and "Reboot Now".
- 14. Disconnect laptop and re-connect the Ethernet cable from the cRIO to the Game Adapter.